

Instructions to get optimal use out of your breathalyzer

<ul style="list-style-type: none"> - After consuming alcohol, wait 20 minutes before carrying out a breath test. - Wait 5 minutes after a cigarette - Wash the mouthpiece after each use. 	<ul style="list-style-type: none"> - Do not leave the device in a car in cold or warm places (store between 10 and 30 °C, ideally). - Do calibrate your device regularly.
--	---

Device calibration

<p>You have just received your breathalyzer, it comes precalibrated. However, do not forget that it is very important to calibrate your device according to its specifications. Your breathalyzer requires maintenance to maintain its effectiveness and efficiency to function properly.</p>	<p align="center">Calibration frequency</p> <p>Generally, it is recommended to check your device every 12 months and/or between 300 and 1000 tests depending on the type of device you own. For more information, refer to the instruction manual.</p>
--	--

Calibration Procedure

By mail	In person
<p>Visit alcoprevention.com, on the home page click on the icon named Information on Calibration and follow the guidelines for sending in your device. Subsequently, you can ship your device by post to the following address:</p> <p>Alco Prevention Canada 4800, Highway 440 West, Suite 3 Laval (Quebec) H7T 2Z8</p> <p>To ensure the delivery and follow-up of your device, <u>we strongly recommend that you obtain confirmation of delivery when shipped.</u></p> <p>The cost of calibration when the device is sent by post is \$45.93, including taxes and, the cost of transportation within Quebec. The cost may be higher if it requires to be sent to the manufacturer.</p> <p>Your product will be verified, calibrated and shipped usually within 5 business days.</p> <p>Information: 1 888 863-8660, extension 2044</p>	<p>Laval office</p> <p>Book an appointment by contacting our customer service line: 1 888 863-8660, extension 2044.</p> <p>The cost for calibration is \$34.44, including taxes when you bring your device to our offices and complete a report following calibration.</p> <p>For all questions, you can reach us at the same number.</p>
	<p align="center">In the region</p> <p>Contact us to find the nearest service center to you:</p> <p>1 888 863-8660, extension 2044.</p>

Alco Prevention Canada,

For good conduct and to protect your employees and your business.